Installation Instructions – T Track



Before Installing – Assess the installation setting suitability

Important: Prior to installation, we recommend confirming the wall structure itself can support the intended artwork weights. Our track systems are strong, but only as strong as the sub-structure they are attached to.

Absolute's T Track, with 300mm hole centres, can support individual artworks weighing up to 150kg (up to 1x 150kg artwork per linear metre). To hang artworks of such weights, the track must be fixed to *continuous* hardwood or plywood platens within the wall structure to support the load. **For advice, please contact us prior to installation**.

- Hold the first section of track in place, usually sitting tightly above the wall panels (or place where wall panelling will go), ensuring the face of the track is flush with the face of the panel, and mark the positions of the track screw holes.
- 2. Drill and fix the first section of track in place, making sure you choose the relevant fixings for the type of wall you are attaching to (4mm diameter screws are best suited to this track. The length of screw is determined by the wall structure.)
- 3. Tap one of the connecting pins (supplied) into the small 2mm hole at the end of the track so that half of pin protrudes and engages with the next section of track, ensuring everything aligns neatly.
- 4. Repeat this process until your reach the last section of track and trim the track to the appropriate length (**Do not trim off the left-hand end with the top block entry mouth**).
- 5. Absolute's T Track is designed to receive a cover to ensure all fixings are discreetly hidden. Once the track is securely installed, carefully insert the cover into place by pushing the top edge of the cover up into place and then pushing the lower edge towards the wall until you hear it click into place.

Tip: For the smoothest overall finish, when installing the cover, we recommend ensuring the cover joints do not align with the track joints, stagger them instead.

Mitre inside and outside corners using a chop saw for a clean continuous finish.

For exposed edges, we can supply end caps for T track if needed. Please request these when ordering.

To hang artworks, you will need to use T Track Hanging Sets (See Hanging Set

Instructions).